AW1600 OS software version up manual<CD>

How to version up

- 1. Copy the latest file 'AW1600PG.BIN' onto your CD-R(ISO format) and put the CD-R on the CD trey.
- 2. Turn off the power of AW1600.

 And turn on again the power with pushing the following both keys.

WORK NAVIGATE

"SONG"

"REMOTE"

//// AW1600 OS UPDATER ////

CHECKING HDD...

LOADING OS FROM CD-ROM...

3. After a few minutes, LCD is displayed as follows. Press "ENTER" key.

(The following display is the example fromV1.00 to V1.10)

//// UPDATE OS VERSION ////

FIRM OS: V1 10 <- V1.00

DO YOU WANT TO UPDATE?

CONTINUE: [ENTER], EXIT: [CANCEL]

4. The following message is displayed in the LCD screen and installation is begun.

//// UPDATE OS VERSION ////

DO YOU WANT TO UPDATE?

CONTINUE: [ENTER], EXIT: [CANCEL]

WRITING OS INTO AW1600. PLEASE DON'T TOUCH AW1600!!

NOTICE!!) Until a result is displayed, don't touch by all means in the main unit.

5. When the installation completes normally, the messages are displayed in the LCD screen as following. And push "ENTER" key and start up OS.

DO YOU WANT TO UPDATE?

CONTINUE: [ENTER], EXIT: [CANCEL]

WRITING OS INTO AW1600. PLEASE DON'T TOUCH AW1600!!

COMPLETED.

RESTART: [ENTER]

The version up is completed.

How to confirm the version

Press "UTILITY" key after turning on the power of AW1600 and YAMAHA logo is displayed at the LCD. When continuing a weight just as it is, the version of installed BOOT and FIRM OS is displayed at the LCD.

AW1600 Copyright (c) 2005 YAMAHA

> B00T 0S: V1. 01 FIRM 0S: V1. 10

BUILD DATE 2005/XX/XX XX:XX:XX

Confirm that it becomes V1.01 BOOT and V1.10 FIRM together.

About the display messages

"CAN'T LOAD OS FILE."

The OS files is not found.

After confirm the file, please try again to make version up from the beginning.

"INCOMPLETED. PLEASE TURN OFF"

The version up is imcompleted.

After confirm the file, please try again to make version up from the beginning.